



The incorrect lift mast tilt angle during lifting operations is one of the main reasons for various load edge damage in today's lift truck handling.

The Bolzoni Auramo Tilt Angle Indicator is an excellent tool to reduce this problem by providing easier, faster and more accurate lift mast positioning control.

The Tilt Angle Indicator consists of a sensor unit and a clearly readable display unit, which continuously shows the lift mast tilting angle.

The indicator system uses a special level sensor mounted on the side of the mast to measure the mast position in relation to the true vertical plane.

The display unit can be conveniently installed into the lift truck cabin to provide optimal visibility.

The clear red, yellow and green indicator lights give accurate tilt angle information even in the most difficult light conditions.

The vertical mast position can easily be achieved by simply following the clear mast position indicator lights while tilting the mast.

The simple and rugged design makes the installation and setup work fast and easy. The system can be installed in virtually any standard lift truck.

After the initial setup, the system is maintenance-free and requires no user operation.



Technical Specifications:

Read-out range	± 9 degrees (standard setting) ± 7 degrees (max accuracy)
Operating Voltage	12 to 24 V DC
Standard configuration	Display unit Mast position sensor Sensor cable

BOLZONI AURAMO CANADA LTD.
90C BRUNSWICK BLVD DOLLARD-DES-ORMEAUX,
QUEBEC - H9B 2C5 CANADA
Tel. 800-685-7871 - Fax 514-685-5238

www.bolzonigroup.com

BOLZONI AURAMO CANADA LTD.
889 PANTERA DRIVE UNIT #6 MISSISSAUGA
ONTARIO - L4W 2R9 CANADA
Tel. 800-685-7871

sales.ca@bolzoni-auramo.com

BOLZONI AURAMO

